



TOKICO Mounting




7

Fit the disc on the wheel hub.




or




8

Push the piston back.




9

Replace the support plates.




10

Introduce the new pads complete with respective plates.




11

Insert the springs and turn the caliper.



12

Reassemble the lower screw.



13


Depress the brake pedal several times to bring the pads together.

TOKICO Dismounting




1

Remove the lower screw.




2

Turn the caliper and remove the springs.




3

Remove the pads and respective plates.




4

Remove the pad support plates.



5

Remove the disc.



6

Dry clean the caliper and the wheel hub.